




JGSP800





Assembly & Instructions



OWNER'S & MANUAL

JGSP800 HARDWARE
(shown in actual size)



A1.M8X75L HEX HEAD SCREW (HALF THREAD) ...2PCS





A2.M8X25L HEX HEAD SCREW...4PCS





A3.M10X25L TAPER FLAT HEAD SOCKET SCREW...6PCS






A4.M10X50L HEX HEAD SCREW...2PCS



A5.M10X65L HEX HEAD SCREW...2PCS




A6.M12X25L SOCKET SCREW ...4PCS




JGSP800 HARDWARE
(shown in actual size)

A7.M12X25L HEX HEAD SCREW...4PCS



A8.M12X85L HEX HEAD SCREW...1PCS



A9.M5X5L COUNTERSUNK SCREW...8PCS(Pre-installed)




A10.M8X15L CUP HEAD SOCKET HEAD CAP SCREW..2PCS(Pre-installed)




C1.M8 SPRING WASHER ...8PCS (2PCS Pre-installed)





C2.M8 WASHER (Ø22) ...6PCS



C3.M10 WASHER (Ø28) ...8PCS




C4.M12 SPRING WASHER ...6PCS




JGSP800 HARDWARE
(shown in actual size)

C5.M12 WASHER (Ø24) ...6PCS




C6.1/2" SPRING WASHER...2PCS




C7.M8 WASHER (Ø16) ...2PCS(Pre-installed)




B1.M12 CAP NUT...1PCS





B2.M10 CAP NUT...4PCS



B3.M12 NUT...2PCS



B4.1/2" CAP NUT...2PCS




JGSP800 HARDWARE


(shown in actual size)

D1.Belt Pulley(9213-002C).....	2PCS
D2.The Round Side Cover(9211-173).....	4PCS
D3.End Cover(8130-248).....	2PCS
D4.End Plug(9211-214).....	4PCS
D5.Stop Plug(9310-057).....	2PCS
D6.Rubber Mat(9310-075).....	2PCS
D7.End Plug(9211-193).....	1PCS
D8.1510mm Steel Cable.....	1PCS
D9.3465mm Steel Cable.....	1PCS
D10.Iron Cover(8510-018)(Pre-installed).....	4PCS
D11.Chrome Collar(8890-061)(Pre-installed).....	2PCS
D12.End Closure(8130-254)(Pre-installed).....	2PCS
D13.Universal Bearing(8510-027)(Pre-installed).....	2PCS
D14.Snap Fastener(9211-118)(Pre-installed).....	2PCS
D15.Snap Fastener(9211-036)(Pre-installed).....	4PCS
D16.The Elliptical Pipe Plug(9211-207)(Pre-installed).....	1PCS
D17.Adjust Team(8250-066)(Pre-installed).....	1PCS
D18.Copper Sheathing(8520-001)(Pre-installed).....	2PCS

D1




D2




D3




D4




D5




D6



D7



D8



D9



D10



D11



D12



D13



D14



D15



D16



D17




D18




JGSP800 HARDWARE (shown in actual size)


A[1PCS]




B[1PCS]




C[1PCS]



D[1PCS]




E[1PCS]
(6640-019)




F[2PCS]
(8313-188)




G[1PCS]
(9121-093)




H[1PCS]




I[1PCS]




J[1PCS]




K[1PCS]
(9111-111)




M[1PCS]





L[1PCS]
(8343-301)







Above shows STEP 1
assembled and completed









Above shows STEP 2
assembled and completed






Above shows STEP 3
assembled and completed





JGSP800

Exploded View



KEY

Match the letters inside
each triangle

- | | | |
|---|----------|---|
|  | connects |  |
|  | connects |  |
|  | connects |  |
|  | connects |  |
|  | connects |  |
|  | connects |  |