





NST.5




Assembly & Instructions

OWNER'S & MANUAL


NST.5 HARDWARE
(shown in actual size)




A1.M10X65L HEX HEAD SCREW.....2PCS





A2.M8X25L ROUND HEAD SCREW.....6PCS





A3.M10X20 TAPER SCREW.....2PCS




C1.M8 WASHER (Ø18)...6PCS




C2.M8 SPRING WASHER ...6PCS




C3.M10 WASHER(Ø28)...2PCS




B1.M12 LOCK NUT...2PCS




A[1PCS]




B[1PCS]




E[1PCS]
(9121-088)



D[1PCS]
(9111-080)



C[1PCS]




NST.5 PARTS


D2.40X80 End Cap (9211-191) ----- [2PCS]


D6.Cushion Mat (9214-045) ----- [2PCS]

D2



D6





Above shows STEP 1
assembled and completed

