PLTE Maintenance



* Customers can put some grease on pivot points(red circle place), with brass or gunmetal bushings.







* Let's maintain your machine!

PLTE.5 PARTS


A [1PCS]




C [1PCS]



D [1PCS]




E [1PCS]



F [1PCS]

H [1PCS]

HR [1PCS]









I [1PCS]

J [2PCS]

K [2PCS]









M [1PCS]
9111072

N [1PCS]
9144016

P [1PCS]
9131025








Q [2PCS]
9131037

R [2PCS]
8323-188

S [1PCS]
9119-010









PLTE.5 PARTS


D2. Steel Casing (8120-084) pre-installed ..... [4PCS]
D3. Steel Casing (8530-009) ..... [2PCS]
D4. Ø50 End Cap (9211-020) ..... [2PCS]
D6. 40x80 End Cap (9211-192) ..... [4PCS]
D7. 50x100 END CAP (9211-193) ..... [4PCS]
D8. Rubber Dount (9310-016) ..... [2PCS]
D9. Rubber Insert (9310-076) ..... [3PCS]
D10. Block Rubber (9310-077) ..... [2PCS]
D11. Pinch Cock (OC-06) ..... [2PCS]
D12. M10 Cap Sleeve (9212-026) ..... [24PCS]
D13. Co er Washer (8520-001) pre-installed ..... [4PCS]
D15. Bearing (8510-003) pre-installed ..... [4PCS]
D16. Bearing (8510-020) pre-installed ..... [4PCS]
D17. Steel Casing (8120-082) pre-installed..... [4PCS]
D18. Impregnated With Handle (9162-163) pre-installed ..... [2PCS]
D19. 60X60 Nylon Bushing (9211-047) ..... [1PCS]
D20. Hydraulic Seat Adjuster (8830-023) pre-installed ..... [1PCS]
D21. Fixed beam (8130-253) pre-installed ..... [2PCS]
D22. Sheath (8890-061) pre-installed ..... [2PCS]
D23. Fixed foot pedestal (9310-018) ..... [2PCS]




Above shows STEP 1
assembled and completed




Above shows STEP 2
assembled and completed




Above shows STEP 3
assembled and completed




Above shows STEP 4
assembled and completed



Above shows STEP 5
assembled and completed



PLTE.5
Exploded View



*Well done!

